

#Jenny



Finally I get this ebook, thanks for all these I can get now!

#Rio



Cool! I'am really happy

#Markus Jensen



I did not think that this would work, my best friend showed me this website, and it does! I get my most wanted eBook

#Hun Tsu



wtf this great ebook for free?!

#Che Salsa



My friends are so mad that they do not know how I have all the high quality ebook which they do not!

#Diego Butler




so many fake sites. this is the first one which worked! Many thanks

FRONT WHEEL/BRAKE/SUSPENSION/STEERING


**FRONT WHEEL**

**REMOVAL**


Remove the adjusting nut and brake cable from the joint pin and cable holder.  
Remove the joint pin from the brake arm.  
Disconnect the speedometer cable from the brake panel by pulling the cable tab.  
Remove the O-ring from the speedometer cable.



Loosen the front axle nut.  
Support the scooter securely using a hoist or equivalent and raise the front wheel off the ground.  
Remove the front axle nut.  
Remove the front axle, side collar and front wheel.




Remove the brake panel from the left side of the wheel.  
Refer to page 14-11 for brake panel disassembly.



**INSPECTION**

**AXLE**

Place the axle in V-blocks and measure the runout.  
Actual runout is 1/2 the total indicator reading.  
SERVICE LIMIT: 0.20 mm (0.008 in)



[Download PDF version of :](#)  
**Honda Ruckus Free Service Manual**